


조립 설명서

3.3 m / 11 ft 마켓 파라솔

ITM. / ART. 1752002

중요: 이 설명서를 잘 읽고 나중에 참고할 수 있도록 보관하십시오.
이 제품은 실외 상업용 및 가정용으로만 사용됩니다.

**문의 사항이나 문제가 있거나 빠진 부품이 있습니까?**

제품을 판매점에 반품하기 전 고객 서비스 부서(1-888-690-9800, 월요일~금요일, 오전 8시~오후 5시 태평양 표준시 / 오전 11시~오후 8시 동부 표준시, 영어 및 스페인어 지원)로 문의하시거나 service@sunvill.com으로 이메일을 보내십시오.

준비 사항

제품 조립을 시작하기 전 부품이 빠짐없이 있는지 확인하십시오. 패키지의 내용물 목록과 하드웨어 목록을 패키지에 포함된 실제 부품과 비교하십시오. 부품이 누락되었거나 손상된 경우에는 제품을 조립하지 마십시오. 작업을 멈추고 고객 서비스 센터로 전화하십시오.

제품을 조립하거나 설치하기 전 설명서의 내용을 모두 읽고 이해하도록 하십시오. 이 제품은 장난감이나 도구로 사용할 수 없습니다.

어린이는 제품의 작동, 조립, 제거, 해체 작업에 참여하지 않도록 하십시오.




조립 시간: 10분. 공구 없이 조립 가능.

⚠ 안전 정보

이 파라솔의 용도는 햇볕을 피할 수 있도록 그늘을 제공하는 것입니다. 바람이 불거나 돌풍 또는 폭풍이 발생한 날씨는 파라솔을 방치하거나, 완전히 펴거나 사용하지 마십시오. 사용하지 않는 기간/계절에는 파라솔을 베이스에서 분리하여 보관하는 것이 좋습니다. 바람이 많이 불거나 혹한의 날씨에 파라솔을 베이스에서 제거하지 않아 제품이나 다른 물건이 분실 또는 손상된 경우에는 제조사와 판매사가 책임지지 않습니다.

부품 목록

⚠ 경고: 새 우산의 손상을 방지하려면 조립 중 제품 손상을 방지하기 위해 상자나 카펫과 같은 부드러운 표면을 작업 표면으로 사용하세요.


부품 번호		명칭	수량
A		상단 프레임 (캐노피 포함)	1
B		하단 폴	1
C		캡	1

중요: 이 설명서를 잘 읽고나중에 참고할 수 있도록 보관하십시오.

조립


1 단계

캡(C)을 시계 방향으로 돌려 우산 윗부분에 끼웁니다.



2 단계


하단 폴(B)을 상단 프레임에 시계 방향으로 조일 때까지 조입니다.



조립 (이어서)


3 단계

파라솔을 적절한 베이스에 고정하십시오(베이스 별도). 열기 전 파라솔의 살을 조심스럽게 서로 떼어내십시오.
우산을 열려면 받줄을 아래로 당기세요.



4 단계

우산이 완전히 열리면 핀을 구멍에 삽입합니다. 로프를 핀 주위에 감고 묶습니다.



조립 (이어서)

5 단계


칼라를 시계 방향으로 돌리면 우산이 기울어지고, 반시계 방향으로 돌리면 우산이 곧게 펴집니다.

참고: 파라솔의 최대 경사인 30도가 되면 기울기가 멈춥니다. 이 정지 지점을 지나 계속 진행하지 마십시오.



6 단계

우산을 닫힌 위치로 되돌리려면 핀을 빼세요. 로프를 풀어 우산을 닫으세요. 사용하지 않을 때는 부착된 끈을 사용하여 우산을 고정하세요.



관리 및 유지 보수

엄브렐라

젖은 덮개는 펼친 채로 햇볕에 건조하십시오.

사용하지 않는 계절에는 건조한 장소에 보관하십시오.

불을 사용하는 곳이나 난방기구 근처에서 사용하지 마십시오.

패브릭

Sunbrella® 원단은 100% 용액 염색 아크릴 섬유로 만들어졌으며, 실외 사용의 높은 요구 사항을 견딜 수 있습니다. 원단을 최상의 상태로 유지하려면 먼지나 얼룩이 처음 보일 때 원단을 세척하는 것이 좋습니다.

원단을 정기적으로 유지 관리하려면 매년 봄철에 세척하는 것이 좋습니다.

먼지를 털어냅니다.

물과 순한 비누로 세척액을 뿌립니다.

부드러운 강모 브러시로 세척합니다.

세척액이 원단에 스며들도록 합니다.

비누 잔여물이 모두 제거될 때까지 철저히 헹굽니다.

자연 건조합니다.

원단의 수명을 유지하려면 사용하지 않을 때는 실내에 보관합니다.

제품보증

야외용 가구 2년 제한 보증 프로그램

제품보증에 따라 제조업체는 구매일로부터 2년 동안 불량 구성품을 수리 또는 교체해드립니다. 이 제품보증은 제조업체와 최초 구매자 사이에 유효하며, 최초 구매일과 구매 장소가 표시된 구입 영수증을 제시하는 경우에만 보장됩니다. 이 제품보증에 따라 교체 시 이후 제품보증은 최초 구매일로부터 다시 시작됩니다.

제조업체 및 공식 판매처는 확인된 사항에 따라 보증 청구를 수락하거나 거절할 수 있습니다. 이 제품보증은 가정에서 정상적으로 사용된 경우에만 적용되며, 상업적인 용도는 보장되지 않습니다. 제조업체는 필요한 재질, 구성품, 부품을 필요에 따라 비슷한 가격이나 용도의 제품으로 대체할 수 있습니다. 이 제품보증은 제품 수리 및 교체(제조업체의 결정에 따라)에 한해 적용됩니다. 보증 및 반품은 영향을 받은 단일 부품에 한해 적용됩니다.

이 제품보증은 제조상 하자인 경우에만 적용되며, 정상적인 사용으로 인한 마모와 찢김, 천재지변으로 인한 손상(동결, 강풍 등이 포함되며 이에 국한되지 않음), 남용 및 오용(선땀용 오일이나 기타 화학물질에 의한 화학적 손상 포함), 과도한 열기나 냉기에 노출, 마모 또는 중량 초과 등으로 인한 손상은 보증이 적용되지 않습니다. 제품이 본래의 용도로 사용되지 않은 경우에는 제품보증이 무효화됩니다. 제조업체는 구성품의 불량으로 인해 발생한 설치 문제나 불편에 대해 책임을 지지 않습니다.

일부 품목은 이 제품보증에 적용되지 않습니다. 여기에는 다음의 항목이 포함되나 이에 국한된 것은 아닙니다.

1. 고장을 시연할 목적으로 오용하는 경우를 포함하여 구성품을 오용한 경우
2. 판매자, 배송업체, 설치 직원에 의한 손상(흠집, 찢힘, 찢김, 부스러짐 등)
3. 육안으로는 일반적인 마모 상태가 확인되지만 새 제품과 동일하게 작동하는 경우(예: 부스러짐, 흠집, 재질이나 봉제 상태의 늘어남 등)
4. 잘못된 설치나 사용으로 인해 발생한 찢김, 구멍, 흠집이나 기타 손상
5. 잘못된 조립, 수분에 노출, 냉각점보다 낮은 온도에서 발생한 프레임/용접 부분의 손상은 보증이 적용되지 않습니다. 프레임의 일반적인 부식은 보증이 적용되지 않습니다.
6. 날씨, 화학물질, 기름, 액체 또는 기타 원인으로 인해 천/쿠션/스트랩/등가구 등의 색이 흐려지거나 변색되는 것은 보증이 적용되지 않습니다.
7. 어떠한 상황에서도 파라솔의 베이스는 보증이 적용되지 않습니다.
8. 이 제품은 '현재 상태 대로' 또는 매장 모델과 같이 판매됩니다.


제품보증을 신청하려면 아래의 무료 전화로 문의하십시오. 전화로 문의할 때는 최초 구입 영수증과 문제에 대한 간단한 설명을 미리 준비해 주십시오. 또한, 이메일 주소와 업무 시간에 연락할 수 있는 전화번호나 휴대폰 번호를 알려주십시오. 모든 품목은 실제 운임에 추가로 취급 수수료 15달러가 청구됩니다. 수리 및 교체는 제조업체의 선택 방법에 따라 처리됩니다. 고객은 판매 및 사용 관련 세금, 배송 및 취급 수수료를 지불해야 합니다.

이 제품보증은 전적으로 명시된 책임에 한해 배타적이고 제한적으로 적용됩니다. 제조업체나 브랜드는 이 품질보증 외에 판매처를 비롯한 타사에서 명시적 혹은 묵시적으로 제공한 기타 품질보증의 책임을 지지 않습니다. 이러한 배타적인 구제책은 이 제품보증에 명시된 조건과 상태에 따라 결함이 있는 것으로 간주되는 제품이나 구성품의 수리 또는 교체와 관련된 크레딧의 수량으로 제한됩니다. 실수, 간접적인 원인, 특수한 원인 또는 제품의 사용으로 인해 부수적으로 발생한 손상, 이 제품보증의 위반이나 부주의로 인해 발생한 손상에 대해 이러한 손상의 가능성이 이미 고지되었더라도 제품의 제조업체나 판매 대리인은 해당 책임을 지지 않습니다. 법률에 의해 요구되는 경우를 제외하고, 이 설명서에 설명된 제품보증 외에는 명시적이거나 묵시적으로 다른 보증이 제공되지 않으며, 판매를 위한 묵시적 보증이나 특정 용도를 위한 적합성 등 다른 모든 보증에 대해서는 책임이 명시적으로 거부됩니다.

3.3 m / 11 ft Market Umbrella

ITM. / ART. 1752002

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.
THIS ITEM IS INTENDED FOR OUTDOOR COMMERCIAL AND DOMESTIC USE ONLY.



Questions, problems, missing parts?

Before returning to your retailer, call our customer service department at 1-888-690-9800 (8:00 a.m. – 5:00 p.m. PT / 11:00 a.m. – 8:00 p.m. ET, Monday – Friday. English and Spanish) or email us at service@sunvilla.com.

Preparation

Before beginning to assemble this product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble this product. Stop and call our customer service center.

Please read and understand this entire manual before attempting to assemble or install the product. It should not be used as a toy or tool.

Children should not engage in the operation, assembly, removal, or disassembly of the product.




Estimated Assembly Time: 10 minutes. Tools Required for Assembly: None.

⚠ Safety Information

The purpose of the umbrella is to provide shade from the sun. Never leave unattended, fully opened, or use in windy conditions, gusts or storms. It is best to remove the umbrella from the base and store when not in use and also in the off season. The manufacturer or retailer is not liable for any loss, damage to the product, or other items due to the failure of not removing the umbrella from an umbrella base during windy-stormy conditions.

Umbrella Parts List

⚠ WARNING: To avoid damage to your new umbrella, please use either the carton or another soft surface such as carpet as a working surface to prevent product damage during assembly.


PART NO.		DESCRIPTION	QTY
A		Upper Frame with Canopy	1
B		Bottom Pole	1
C		Cap	1

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Umbrella Assembly


Step 1

Screw the Cap (C) into the top of the umbrella by rotating it clockwise.



Step 2

Screw Bottom Pole (B) into the upper frame by rotating it clockwise




Umbrella Assembly (cont.)

Step 3

Secure the umbrella into an appropriate umbrella base (not included).


Before opening, gently pull apart and separate the umbrella ribs.

Pull the rope down to open the umbrella.



Step 4

Insert the pin into the hole when the umbrella is fully open. Wrap the rope around the pin and tie it.



Umbrella Assembly (cont.)

Step 5


Turn the collar either clockwise to tilt the umbrella or turn it counterclockwise to straighten the umbrella.

Note: The umbrella will stop tilting at the maximum tilt of 30 degrees. Do not continue past this stopping point.



Step 6

To return the umbrella to the closed position, pull out the pin. Loosen the rope to close the umbrella. Use the attached ties to secure your umbrella when not in use.



Care and Maintenance

Umbrella

Allow a wet canopy to dry in the open position in the sunlight.

Store in a dry place during the off season.

Keep the umbrella away from fire or heat sources.

Fabric

Sunbrella® fabrics are made of 100% solution-dyed acrylic fibers which are capable of withstanding the high demands of outdoors use.

To keep your fabric looking its best, we suggest cleaning the fabric at the first signs of dirt or stains.

For routine maintenance of your fabrics, we recommend cleaning each spring season.

Brush off loose dirt.

Spray on a cleaning solution of water and mild soap.

Use a soft bristle brush to clean.

Allow cleaning solution to soak into the fabric.

Rinse thoroughly until all soap residue is removed.

Air dry.

To maintain the life of the fabric, store indoors when not in use.

Warranty

Outdoor Furniture

2-YEAR LIMITED WARRANTY

For a period of two (2) years after date of purchase, the Manufacturer will either repair or replace defective components in accordance with this Limited Warranty. This warranty is between the Manufacturer and the original purchaser and is valid only when accompanied by the original purchaser's sales receipt showing original date of purchase and location of purchase. Replacements under this warranty revert back to the date of original purchase for future warranty.

The manufacturer or its authorized dealer can accept or reject warranty claims based on its findings. This warranty applies in normal residential use only and is not intended for commercial use. The Manufacturer can make substitutions as required of materials, components, and subcomponents of comparable value and utility. This warranty is limited to product repair or replacement (to be determined solely by the manufacturer). Warranty return is limited to only the single affected component.

This limited warranty covers only manufacturing defects and does not cover normal wear and tear, damage due to acts of nature (such as, but not limited to freezing or high winds), abuse or misuse, including chemical damage from suntan oil or other chemicals, exposure to extreme heat or cold, abrasion or excessive weight. This product is intended to be used in standard installations only. This warranty is void if the product is not used for its intended purpose. The Manufacturer disclaims liability for any aspect of installation and any inconvenience caused by a defective part of a component.

Certain items are not covered by this warranty. These include, but are not limited to the following:

1. Components subjected to abuse, including abuse intended to simulate failure.
2. Damages caused by retailer, shipper or installation crew (such as scratches, dents, tears, chips, etc.).
3. Any part which merely exhibits normal wear yet functions essentially as new, including chips, scratches or stretching of materials and stitching.
4. Tears, punctures, scratches or any damage caused by improper installation or use.

5. Damage to frames/welds resulting from improper assembly or exposure to water and/or sub-freezing temperatures is not covered. General frame rusting is not covered.

6. Fading and/or discoloration of fabrics/cushions/straps/wicker resulting from exposure to the elements, chemicals, oils, fluids or any other cause are not covered.

7. Umbrella bases are not covered under any circumstances.

8. Items sold "as is" or floor models.

To make a claim, call the toll-free number below. Please have available a copy of the original sales receipt along with a brief description of the problem. Please also provide your email address and daytime telephone or cell phone number. All items may be charged actual freight costs plus \$15 for handling. Repairs or replacement will be made at the Manufacturer's option. Sales and use taxes, plus shipping and handling charges are the responsibility of the consumer.

THIS IS THE ENTIRE EXCLUSIVE EXPRESS LIMITED LIABILITY. THE MANUFACTURER NEITHER MAKES NOR IS RESPONSIBLE FOR ANY OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING THOSE OF RETAILING DEALERS. THIS EXCLUSIVE REMEDY IS LIMITED TO RECEIPT OF A CREDIT IN CONNECTION WITH THE REPAIR OR REPLACEMENT OF ANY PRODUCT OR COMPONENT DEEMED TO BE DEFECTIVE UNDER THE TERMS AND CONDITIONS AS STATED IN THIS WARRANTY. NEITHER THE PRODUCT MANUFACTURER NOR ITS AGENTS SHALL BE LIABLE IN ANY CASE FOR INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY OR NEGLIGENCE EVEN IF IT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCEPT AS OTHERWISE MAY BE REQUIRED BY LAW, THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OTHER THAN THE WARRANTY DESCRIBED HEREIN, AND ALL OTHER WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY DISCLAIMED.

AUSTRALIA: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

SUNVILLA

Distributed by:
Costco Wholesale
Corporation P.O. Box 34535
Seattle, WA 98124-1535
USA
1-800-774-2678
www.costco.com

Costco Wholesale Canada Ltd.*
415 W. Hunt Club Road
Ottawa, Ontario
K2E 1C5, Canada
1-800-463-3783
www.costco.ca
* faisant affaire au Québec sous
le nom les Entrepôts Costco

Importado por:
Importadora Primex S.A. de C.V.
Blvd. Magnocentro No. 4
San Fernando La Herradura
Huixquilucan, Estado de México
C.P. 52765
RFC: IPR-930907-S70
(55)-5246-5500
www.costco.com.mx

Costco Wholesale Australia Pty Ltd
17-21 Parramatta Road
Lidcombe NSW 2141
Australia
www.costco.com.au

Costco Wholesale UK Ltd /
Costco Online UK Ltd
Hartspring Lane
Watford, Herts
WD25 8JS
United Kingdom
01923 213113
www.costco.co.uk

Costco Wholesale Spain S.L.U.
Polígono Empresarial Los Gavilanes
C/ Agustín de Betancourt, 17
28906 Getafe (Madrid) España
NIF: B86509460
900 111 155
www.costco.es

Costco Wholesale Iceland ehf.
Kauptún 3-7, 210 Gardabaer
Iceland
www.costco.is

Costco France
1 avenue de Bréhat
91140 Villebon-sur-Yvette
France
01 80 45 01 10
www.costco.fr

Costco Wholesale Japan Ltd.
2 Kakuchi, 2 Gaiku, Kaneda-Nishi
361 Urikura, Kisarazu shi
Chiba, 292-0007 Japan
0570-200-800
www.costco.co.jp

Costco Wholesale Korea, Ltd.
40, Iljik-ro
Gwangmyeong-si
Gyeonggi-do, 14347, Korea
1899-9900
www.costco.co.kr

Costco Wholesale New Zealand Limited
2 Gunton Drive
Westgate
Auckland 0814
New Zealand
www.costco.co.nz

Costco (China) Investment Co., Ltd.
Room 01 Mezzanine
No. 5178, Kang Xin Highway
Pudong New District
Shanghai
China 201315
+86-21-6257-7065

Costco Wholesale Sweden AB
Box 614
114 11 Stockholm
Sweden
www.costco.se

MADE IN CHINA
FABRIQUÉ EN CHINE
HECHO EN CHINA