















# 9 Piece Sling Dining Set

ITM. / ART. 2127070

## ASSEMBLY / CARE & USE INSTRUCTIONS

**IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY**  
THE ITEM IS INTENDED FOR OUTDOOR DOMESTIC USE ONLY, NOT FOR COMMERCIAL USE.



PART NO.	A	B	C	D	AA	BB	CC
PICTURE					 M6X45	 M6X60	 M8X45
QTY	2	2	2	2	8	4	8
PART NO.	DD	EE	FF	GG	HH	II	
PICTURE			 M8	 M6			
QTY	8	8	8	4	4	2	

Questions, problems, missing parts? Before returning to your retailer, call our customer service department at **1-888-690-9800** or email us at [cs@sunvillahome.com](mailto:cs@sunvillahome.com)  
8:30 a.m. – 5:00 p.m. PT / 11:30 a.m. - 8:00 p.m. ET, Monday - Friday. English and Spanish.

### PREPARATION


Before beginning to assemble this product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble this product. Stop and call our customer service center.

Estimated Assembly Time: 90 minutes (2 persons). Tools Required for Assembly: Wrench (included.)


### SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble or install the product. It should not be used as a toy or tool. Children should not engage in the operation, assembly, removal, or disassembly of the product.


Step # 1




Step # 2




Step # 3




Step # 4












Step # 5



Step # 6





PART NO.	E	F	G		
PICTURE					
QTY	6	6	6		
PART NO.	AA	BB	GG	HH	JJ
PICTURE	 M6X45	 M6X60	 M6		
QTY	24	12	12	12	2

#### Frame and fabric


- Hand wash with mild soap and rinse thoroughly with water. Dry with a soft cloth.
- Do not use abrasive cleaners or scrub too rough as it may mar the surface.
- Cover and store all furniture during freezing temperature to prolong your furniture and avoid damage to the frames.

#### Chair fabric


Sunbrella® fabric should be cleaned regularly. Brush off any loose dirt and wash with a mild soap and lukewarm water solution. For stubborn stains and mildew, wash with a solution of 236 ml (1 cup) of bleach and 59 ml (1/4 cup) of mild soap per 3.8 l (1 gallon) of water. Rinse thoroughly to remove soap. Allow fabric to air dry.

Note: Do not machine wash.


Step # 1




Step # 2




Step # 3




Step # 4




Step # 5






PART NO.	H	I	J	K	L	M	CC	II
PICTURE								
							M8x45	
QTY	4	1	1	1	1	1	8	1


Step # 1



Step # 2



Step # 3



## CARE AND MAINTENANCE

### Frame

- Do not use abrasive cleaners or scrub too rough as it may mar the surface.

### Umbrella Usage Warning:

This table is not designed to support an umbrella by itself. Use of an umbrella with this table requires an umbrella base (not included).

The table also includes an umbrella hole ring, please make sure it is inserted into the hole in the center of the table before inserting the umbrella.

Any umbrellas larger than 3.04 m / 10 ft should not be used for this table.

CARE AND MAINTENANCE

Periodic Maintenance For Your Stone Table Top

Your stone tabletop is coated at the factory with a protective stone sealant. The sealer provides resistance from stains and moisture and helps maintain the stone’s natural color. For optimum protection, stone tops should be resealed every 6 to 12 months after it has been thoroughly cleaned of all dirt and debris. Stone sealer is available at most club and hardware stores. Use of place mats, table runners, and beverage coasters will help in the prevention of scratches, stains, and will catch potential spills. Use an outdoor furniture cover to protect your investment when not in use.

Cleaning Your Stone Table Top

Your stone table top is virtually maintenance free. Maintain the new look of your stone top by removing dust and dirt with plain water periodically. Occasionally rinse off your table top to prevent debris from settling in and to prevent stains or discolorations. You can also use a mild detergent mixed with water and scrub the table top with a soft, clean cloth or sponge. Immediately dry your table top after cleaning to prevent moisture penetration and water spots. Spills should be cleaned up immediately as they may begin to penetrate the sealant. For more thorough cleaning of the table top use a water-based biodegradable cleaner. Avoid ammonia-based cleaners, which can break down the sealant and possibly damage or discolor the stone. You should never use scouring creams, abrasive cleansers, vinegar cleaners, acid based products or any alkaline-based products such as ammonia, baking soda or borax.

Cold Climates

We recommend that your stone top be stored in a dry area in cold climates or be covered with a suitable outdoor furniture cover. Make a tent with the cover so that it is not touching any part of the tabletop, this will promote airflow and allow moisture to escape. It is possible that prolonged contact with snow can cause moisture to penetrate the sealant on the tabletop. Stone is porous, and if moisture were to enter the stone and freeze, the stone may crack. Always seal the tabletop before each winter for added protection.

Hot Climates


The porous nature of stone leaves it susceptible to heat retention. Care and caution should be used when handling a stone top that has been subjected to lengthy sun exposure. It is recommended that you use this product under a protective shade canopy.

# 9 피스 슬링 다이닝 세트

품목번호. 2127070

조립·관리·사용 설명서

중요! 나중에 참고할 수 있도록 잘 보관하십시오: 주의 깊게 읽으시기 바랍니다  
본 제품은 가정용 야외 전용 제품입니다. 영업용 목적으로 사용하지 마십시오.



부품 번호	A	B	C	D	AA	BB	CC
부품 그림					 M6X45	 M6X60	 M8X45
수량	2	2	2	2	8	4	8
부품 번호	DD	EE	FF	GG	HH	II	
부품 그림			 M8	 M6			
수량	8	8	8	4	4	2	

문의사항, 문제, 누락된 부품이 있습니까? 판매점에 반품하기 전에 고객센터센터 1-888-690-9800 또는 이메일 [cs@unvillahome.com](mailto:cs@unvillahome.com) 로 연락 주시기 바랍니다. 오전 8:30– 오후 5:00 PT/ 오전 11: 30– 오후 8:00 ET, 월 - 금. 영어 및 스페인어 제공.

## 준비

본 제품의 조립을 시작하기 전에 모든 부품이 있는지 확인하십시오. 부품과 패키지 내용물 목록 및 하드웨어 내용물 목록을 비교해 보십시오. 누락되거나 손상된 부품이 있으면 본 제품을 조립하지 마십시오. 작업을 중단하고 고객센터센터로 연락하십시오.


조립 예상 시간: 60분(2명). 조립에 필요한 도구: 렌치(포함되어 있음)

## ! 안전정보


조립 또는 제품 설치를 하기 전에 본 설명서 전체를 읽고 숙지하십시오. 본 제품을 장난감 또는 도구로 사용하면 안 됩니다. 어린이는 제품의 조작, 조립, 철거, 분해에 관여하면 안 됩니다.




단계 # 1




단계 # 2




단계 # 3



단계 # 4




단계 # 5



단계 # 6







부품 번호	E	F	G		
부품 그림					
수량	6	6	6		
부품 번호	AA	BB	GG	HH	JJ
부품 그림	 M6X45	 M6X60	 M6		
수량	24	12	12	12	2

## 관리 및 유지보수

### 프레임과 직물


- 순한 비누로 손 세척 한 후 물로 완전히 행구어 냅니다. 부드러운 천으로 물기를 닦아냅니다.
- 마모성 세제를 사용하거나 너무 거칠게 밀면 안 됩니다. 표면을 손상시킬 수 있습니다.
- 가구의 수명을 늘리고 프레임이 손상되지 않으려면 영하의 온도에서는 모든 가구에 덮개를 씌워 보관하십시오.

### 의자의 직물


Sunbrella® 직물은 정기적으로 세척해야 합니다. 먼지를 털어내고 순한 비누와 미지근한 물로 닦으십시오. 지우기 힘든 얼룩 및 곰팡이는 물 3.8 l (갤런)에 표백제 236 ml (1 컵)와 순한 비누 59 ml (1/4컵)를 넣어 만든 용액으로 세척합니다. 완전히 행구어 비누를 제거합니다. 직물은 공기 중에 자연 건조시킵니다.

주:세탁기 사용 금지


단계 # 1




단계 # 2




단계 # 3




단계 # 4




단계 # 5






부품 번호	H	I	J	K	L	M	CC	II
부품 그림								
수량	4	1	1	1	1	1	8	1


단계 # 1



단계 # 2



단계 # 3



## 관리 및 유지보수

### 프레임

- 마모성 세제를 사용하거나 너무 거칠게 밀면 안 됩니다. 표면을 손상시킬 수 있습니다.

### 파라솔 사용방법에 대한 경고

본 테이블은 파라솔 자체를 지지하도록 설계되어 있지 않습니다. 본 테이블과 파라솔을 함께 사용할 경우 파라솔 받침대(미포함)가 필요합니다.

테이블에는 파라솔 홀 링이 포함되어 있습니다. 파라솔을 끼우기 전에 테이블 중앙에 있는 구멍에 삽입하십시오. 3.04 m / 10 ft 보다 큰 파라솔은 본 테이블에 사용하면 안 됩니다.

관리 및 유지보수

석재 테이블 상판의 정기 보수

본 석재 테이블은 공장에서 보호용 석재 실러로 코팅한 것입니다. 실러는 얼룩 및 수분 저항 특성을 제공하며 석재의 자연색을 유지해 줍니다. 최적의 보호를 위하여 석재 상판은 모든 먼지와 이물질을 완전히 씻어낸 후 **6-12** 개월마다 실러를 다시 바르십시오. 석재 실러는 대부분의 매장과 칠물점에서 구입할 수 있습니다. 매트, 테이블 러너, 컵 받침을 사용하면 긁힘과 얼룩을 방지하고 액체가 옆질러질 경우 잡을 수 있습니다.

사용하지 않을 때는 야외용 가구 커버를 사용하여 제품을 보호하십시오.

석재 테이블 상판 세척

본 석재 테이블은 사실상 유지보수가 필요하지 않습니다. 정기적으로 보통 물로 먼지와 이물질을 제거하면 석재 상판을 신제품과 같이 유지할 수 있습니다. 이물질이 남아 있는 것을 방지하고 얼룩 또는 변색을 방지하려면 가끔 상판을 씻으십시오. 순한 세제를 물과 섞은 다음 부드럽고 깨끗한 천이나 스폰지로 문질러 청소할 수 있습니다. 수분 침투와 물 자국이 생기는 것을 방지하려면 세척 후 테이블 상판의 물기를 즉시 닦아내십시오. 옆질러진 액체는 즉시 닦아내야 합니다. 실런트에 침투할 수 있습니다. 테이블 상판을 좀 더 완전히 청소하려면 생물분해가 용이한 수성 세제를 사용하십시오. 암모니아성 세제는 사용하지 마십시오. 실런트를 분해하여 석재를 손상시키거나 탈색이 될 수 있습니다. 정련용 크림, 마모성 세제, 식초 세정제, 산 성분 제품, 또는 암모니아, 베이킹 소다, 붕사와 같은 알칼라인 성분 제품은 절대 사용하면 안 됩니다.

저온 기후

저온 기후에서는 석재 상판을 건조한 장소에 보관하거나 적합한 옥외 가구 커버로 덮어 두는 것이 좋습니다. 테이블 상판 어느 부분에도 닿지 않게 커버로 텐트를 만들면 통풍이 잘되고 습기가 빠져 나갈 수 있습니다. 장기간 테이블 상판에 눈이 쌓여 있으면 수분이 실러에 침투할 수 있습니다. 석재에는 구멍이 있기 때문에 석재에 수분이 들어가 얼면 테이블 상판이 갈라질 수 있습니다. 추가 보호를 위해 겨울이 되기 전에 테이블 상판에 항상 실러를 바르십시오.

고온 기후

석재에는 구멍이 있기 때문에 열 보유에 민감합니다. 장기간 햇빛에 노출된 석재 상판을 다룰 때는 조심하고 주의해야 합니다. 본 제품은 보호용 그늘막 아래에서 사용하는 것이 좋습니다.

Distributed by:  
Costco Wholesale Corporation  
P.O. Box 34535  
Seattle, WA 98124-1535  
USA  
1-800-774-2678  
www.costco.com

Costco Wholesale Canada Ltd.\*  
415 W. Hunt Club Road  
Ottawa, Ontario  
K2E 1C5, Canada  
1-800-463-3783  
www.costco.ca  
\* faisant affaire au Québec sous  
le nom les Entrepôts Costco

Importado por:  
Importadora Primex S.A. de C.V.  
Blvd. Magnocentro No. 4  
San Fernando La Herradura  
Huixquilucan, Estado de México  
C.P. 52765  
RFC: IPR-930907-S70  
(55)-5246-5500  
www.costco.com.mx

Costco Wholesale Australia Pty Ltd  
17-21 Parramatta Road  
Lidcombe NSW 2141  
Australia  
www.costco.com.au

Costco Wholesale UK Ltd /  
Costco Online UK Ltd  
Hartspring Lane  
Watford, Herts  
WD25 8JS  
United Kingdom  
01923 213113  
www.costco.co.uk

Costco Wholesale Spain S.L.U.  
Polígono Empresarial Los Gavilanes  
C/ Agustín de Betancourt, 17  
28906 Getafe (Madrid) España  
NIF: B86509460  
900 111 155  
www.costco.es

Costco Wholesale Iceland ehf.  
Kauptún 3-7, 210 Gardabaer  
Iceland  
www.costco.is

Costco France  
1 avenue de Bréhat  
91140 Villebon-sur-Yvette  
France  
01 80 45 01 10  
www.costco.fr

Costco Wholesale Japan Ltd.  
3-1-4 Ikegami-Shincho  
Kawasaki-ku, Kawasaki-shi,  
Kanagawa 210-0832 Japan  
0570-032600  
www.costco.co.jp

Costco Wholesale Korea, Ltd.  
40, Iljik-ro  
Gwangmyeong-si  
Gyeonggi-do, 14347, Korea  
1899-9900  
www.costco.co.kr

Costco Wholesale New Zealand Limited  
67 Maki Street  
Massey, Auckland 0814  
New Zealand

Shanghai Minhang Costco Trading Co., Ltd  
No.235 ZhuJian Road  
Minhang District, Shanghai  
China 201106  
+86-21-6257-7065

Costco Wholesale Sweden AB  
Saluvägen 5  
187 66 Täby  
Sweden